

Tools Required – none

Parts Included - none

Cleaning Supplies Required – wax/polish, vinyl dressing, micro fiber towels

Pre-Installation

- 1) Carefully read and follow instructions to ensure optimal performance
- 2) Thoroughly wash & wax vehicle surfaces including inside wheel wells and under front bumper, to prevent entrapment of moisture and/or debris between paint finish and *SpeedLingerie*.
- 3) Place unfolded *SpeedLingerie* in direct sunlight, or near (but not in direct contact with) any radiant heat source for 20-30 minutes to warm-up the *SpeedLingerie*. Park the car in direct sunlight to warm-up the front-end surface.
NOTE! Warming the *SpeedLingerie* and the vehicle front-end will make the *SpeedLingerie* more flexible and easier to install.

Hood Boot Installation

- 1) Open the hood.
- 2) Slide the hood boot onto the hood.
- 3) Attach the passenger side tension cord, to the closest hood insulation pin on the passenger side.
- 4) Attach the driver side tension cord, to the closest hood insulation pin on the driver side.
- 5) Use your fingers to **"tuck" the inner seam at the front and sides edges of the hood, UNDER the front and sides edges, and UNDER the corners** of the hood, to provide a smooth seamless look and sufficient clearance to close the hood properly.
- 6) Close the hood.

Final Adjustment

- 1) Adjust *SpeedLingerie* where necessary, to assure proper fit.
- 2) For full effect of *SpeedLingerie* design and glove-like fit, allow 72 hours for material(s) to relax and conform to vehicle's curves.
- 3) Park in a warm sunny spot with *SpeedLingerie* on for a few days, to help the process.
- 4) You may apply a quality vinyl conditioner to the *SpeedLingerie* if you so desire.

Care & Maintenance

1. For best results, vehicle surfaces must be washed and waxed, to ensure they are clean and dry before installing *SpeedLingerie*.
2. Always inspect *SpeedLingerie* fasteners and surfaces that contact vehicle for possible debris, sand, grit, etc and remove before installation (see step #7).
3. Remove *SpeedLingerie* before washing the vehicle.
4. Remove *SpeedLingerie* after exposure to rain or other fluids/moisture and allow it to hang dry.
5. Clean outer vinyl surfaces of *SpeedLingerie* with a high quality vinyl conditioner during routine car maintenance.
6. Clean felt inner surface with a shop vacuum (or shake it out) to remove any particles. If the inner surface is *very* muddy or dirty, use low-pressure fresh clean water to rinse it out and allow it to hang dry completely.
7. Rubber will stain vinyl. DO NOT store your *SpeedLingerie* in direct contact with any rubber products (tires, hoses, etc.) as vinyl is a very porous material and will absorb the black carbon in rubber products, resulting in a stain.

Stand back and admire your work. Congratulations on your purchase. Enjoy that Corvette!

For installation questions call 650-964-2584 or email us at info@speedlingerie.com.