



*World's Finest Automotive Bra*

*Nose Cover (NCV) Installation - Corvette C5 & C5/Z06 (1997-2004)*

**Tools Required** - 7mm socket wrench

**Parts Included** – Two (2) Universal-sided FasTrak Mounting Brackets

**Suggested Cleaning Supplies** – wax/polish, vinyl dressing, micro fiber cloths

### Pre-Installation

- 1) Carefully read and follow instructions, to ensure optimal installation and performance.
- 2) Thoroughly wash & wax vehicle surfaces, including inside wheel wells and under front bumper, to prevent entrapment of moisture and/or debris between paint finish and *SpeedLingerie™*
- 3) Place vehicle and unfolded *SpeedLingerie™* in direct sunlight, or near (but not in direct contact with) a radiant heat source for at least 30 minutes to make *SpeedLingerie™* more flexible and easier to install.
- 4) Orient yourself with *SpeedLingerie™*. Notice the placement of logo window at top center of *SpeedLingerie™*.
- 5) Turn steering wheel completely to passenger side, for easier access to driver side wheel-well.

### FasTrak™ Bracket Installation

- 1) Remove protective coating from all sides of both brackets. At driver side inner front wheel well, use 7mm socket wrench to **LOOSEN** 3 screws, with 5 counterclockwise turns. **DO NOT FULLY EXTRACT SCREWS.**
- 2) Install a FasTrak bracket between wheel well surface and screws, tab end down, unslotted edge facing **INWARD**. Securely fasten wheel well screws.
- 3) Turn steering wheel completely to driver side, for easier access to passenger side wheel-well.
- 4) At passenger side inner front wheel well, repeat Step #1 and #2.
- 5) Pull hood latch; raise hood.

### SpeedLingerie™ Installation

- 1) Facing the vehicle, hold properly oriented *SpeedLingerie™* outstretched in front of you.
- 2) At passenger side, run your thumb through length of *QuiKlip™* to "open it up" slightly. This will make it easier to fasten *QuiKlip™* onto *FasTrak™* bracket. Using a key or credit card, enfold 5-inch quick release strap within *QuiKlip™*, if applicable. This ensures easy removal of *SpeedLingerie™*. **Do not pull on this strap during installation.**
- 3) Start at bottom of wheel well and fasten *QuiKlip™* onto *FasTrak™* bracket. Do not yet attach small upper *QuiKlip™* section; see Step 8.
- 4) Turn steering wheel completely to passenger side, for easier access to driver side wheel well.
- 5) NOTE! Due to the perfectly tailored fit of *SpeedLingerie™*, step #6 takes careful effort. Acquire assistance, to provide "slack" from the front-end midpoint. **Do not pull on the *QuiKlip™*/stitching itself. Do not pull from the top edge.** The first installation is a new process with a new bra. The goal is a tight fit. It becomes easier with repeated use.
- 6) Working from the passenger side across, carefully but firmly stretch *SpeedLingerie™* towards driver side. Gather 6-8" of material at *QuiKlip™* in your hands. Slowly and firmly stretch from midpoint (side marker level) and lower corner (spoiler level); you may need to repeat this several times for material to "give and stretch". Repeat steps #2 & 3 to fasten *QuiKlip™* on he driver side *FasTrak™* bracket. Do not yet attach small upper *QuiKlip™* section.
- 7) Attach top center *QuiKlip™* (at top seam of *SpeedLingerie™*) to the body edge at the front of the engine bay.
- 8) At passenger side, attach small upper section of *QuiKlip™* onto wheel well edge by placing palms on fender, wrapping fingers over *QuiKlip™* and pressing into place. You should hear *QuiKlip™* "click" into place.
- 9) Repeat step#8 on driver side.

### Mirror Cover Installation - optional

1. To differentiate between passenger and driver side mirror cover, the vinyl covered loop portion of the hook & loop fastener folds **down and over** the hooked portion.
2. Lower/open windows. Close doors. Enjoy the opportunity to work with your car and take your time.
3. Begin at passenger side. Open the hook & loop tab.

**Mirror Cover Installation (optional) - continued**

4. Stretch out mirror cover tension cord and slip the cover over the mirror head. NOTE! Support the mirror head properly during installation by facing the vehicle door.
5. Form the mirror cover into place using both hands and temporarily fasten the hook and loop tab.
6. With both hands, continue forming the mirror cover into place (like molding clay). You may need to open/close hook & loop tab several times during this process. Adjust material around face of mirror until mirror-opening edges at tension cord align and meet.
7. Repeat Steps # 2 – 6 at driver side.

**Final Adjustment**

1. Adjust *SpeedLingerie™* where necessary, to assure proper fit.
2. For full effect of *SpeedLingerie™* design and glove-like fit, allow at least 72-hours for the materials to relax and conform to the curves of the vehicle.
3. Parking in a warm spot for a few days with *SpeedLingerie™* installed helps the process.
4. You may apply a quality vinyl conditioner to add shine and make it easier to wipe clean in the future. Spray the conditioner into the cloth and then apply to the Nose Cover. Do not soak the threads.

**Care & Maintenance**

1. For best results, vehicle surfaces must be washed and waxed, to ensure they are clean and dry before installing *SpeedLingerie™*
2. Always inspect *SpeedLingerie™* fasteners and surfaces that contact vehicle for possible debris, sand, grit, etc and remove before installation (see step #7).
3. Periodically remove to allow complete aeration of vehicle paint finish and *SpeedLingerie™* materials.
4. Remove *SpeedLingerie™* before washing vehicle.
5. Remove *SpeedLingerie™* after exposure to rain or other fluids/moisture.
6. Clean outer vinyl surfaces of *SpeedLingerie™* with a high quality vinyl conditioner during routine car maintenance.
7. Clean felt inner surface with a shop vacuum (or shake it out) to remove any particles. If the inside is *very* muddy or dirty, use low pressure fresh clean water to rinse it out and allow it to dry completely.
8. Rubber will stain vinyl. DO NOT store your *SpeedLingerie™* in direct contact with any rubber products (tires, hoses, etc) as vinyl is a very porous material and will absorb the black carbon in rubber products, resulting in a stain.

**For installation questions call 650-964-2584 or email us at [info@speedlingerie.com](mailto:info@speedlingerie.com).**

Congratulations on your purchase.